



# Vertical Air Compressors


## Compresseurs d'Air Verticaux

## Compressores de Aire Verticales

Replacement Parts List  
 Liste de Pièces de Rechange  
 Lista de Repuestos

VT558804, VT619503, VT627503,  
 VT623803, VT630100, VT630500, VT6310, and VT6312

For parts, products & service information visit  
**POWER XPERT**  
[www.chpower.com](http://www.chpower.com)



## For Replacement Parts, Call 1-800-543-6400

Please provide following information:

- Model number
- Serial number (if any)
- Part description and number as shown in parts list

Address parts correspondence to:

The Campbell Group / Attn: Parts Dept.  
100 Production Drive  
Harrison, OH 45030

Ref. No.	Description	Part Number for Models:				VT6312	VT630500	VT6310	Qty.
		VT558804	VT619503	VT627503	VT623803	VT630100			
1	Tank	AR040000BR	AR040000BR	AR040000BR	AR040000BR	AR232400BR	AR040000BR	AR040000BR	1
2	Drain cock	D-1401	D-1401	D-1401	D-1401	ST127700AV	D-1401	D-1401	1
3	Electric motor	MC006101AJ	MC015401AJ	MC017501AJ	MC015401AJ	MC017501AJ	MC017501AJ	MC017501AJ	1
4	Key	KE000903AV	KE000903AV	KE000903AV	KE000903AV	KE000903AV	KE000903AV	KE000903AV	1
5	Hex head screw	ST016000AV	ST016000AV	ST016000AV	ST016000AV	ST016000AV	ST016000AV	ST016000AV	4
6	Washer	ST011200AV	ST011200AV	ST011200AV	ST011200AV	ST011200AV	ST011200AV	ST011200AV	1
7	Locknut	ST146000AV	ST146000AV	ST146000AV	ST146000AV	ST146000AV	ST146000AV	ST146000AV	4
8	Nipple	HF002401AV	HF002401AV	HF002401AV	HF002401AV	HF002401AV	HF002401AV	HF002401AV	1
9	Pressure switch	CW209300AJ	CW209300AJ	CW209300AJ	CW209300AJ	CW209300AJ	CW209300AJ	CW209300AJ	1
10	Motor cord	EC012800AV	EC012800AV	EC012800AV	EC012800AV	EC012800AV	EC012800AV	EC012800AV	1
11	ASME Safety valve	V-215105AV	V-215105AV	V-215105AV	V-215105AV	V-215105AV	V-215105AV	V-215105AV	1
12	Plug	ST022500AV	ST022500AV	ST022500AV	ST022500AV	ST022500AV	ST022500AV	ST022500AV	1
13	Gauge	GA016700AV	GA016700AV	GA016700AV	GA016700AV	GA016700AV	GA016700AV	GA016700AV	1
14	Unloader valve	CW210000AV	CW210000AV	CW210000AV	CW210000AV	CW210000AV	CW210000AV	CW210000AV	1
15	Check valve	CV221502AJ	CV221502AJ	CV221502AJ	CV221502AJ	CV221502AJ	CV221502AJ	CV221502AJ	1
16	Ferrule	ST067300AV	ST067300AV	ST067300AV	ST067300AV	ST067300AV	ST067300AV	ST067300AV	1
17	Discharge tube	VT043300AP	VT043300AP	VT043300AP	VT043300AP	VT043300AP	VT043300AP	VT043300AP	1
18	Compression nut	ST033001AV	ST033001AV	ST033001AV	ST033001AV	ST033001AV	ST033001AV	ST033001AV	1
19	Push-in fitting	ST081301AV	ST081301AV	ST081301AV	ST081301AV	ST081301AV	ST081301AV	ST081301AV	1
20	Unloader tube	ST117802AV	ST117802AV	ST117802AV	ST117802AV	ST117802AV	ST117802AV	ST117802AV	1
21	Pump	VT470000KB	VT470000KB	VT470000KB	VT470000KB	VT470000KB	VT470000KB	VT470000KB	1
22	Oil drain plug	ST022300AV	ST022300AV	ST022300AV	ST022300AV	ST022300AV	ST022300AV	ST022300AV	1
23	Oil drain cap	ST150100AV	ST150100AV	ST150100AV	ST150100AV	ST150100AV	ST150100AV	ST150100AV	1
24	Oil drain extension	ST083800AV	ST083800AV	ST083800AV	ST083800AV	ST083800AV	ST083800AV	ST083800AV	1
25	Compression assembly	ST018300AV	ST018300AV	ST018300AV	ST018300AV	ST018300AV	ST018300AV	ST018300AV	1
26	Self-tapping screw	ST016500AV	ST016500AV	ST016500AV	ST016500AV	ST016500AV	ST016500AV	ST016500AV	4
27	Belt	BT020400AV	BT020400AV	BT020400AV	BT020400AV	BT020400AV	BT020400AV	BT020400AV	1
28	Flywheel	PU015900AG	PU015900AG	PU015900AG	PU015900AG	PU015900AG	PU015900AG	PU015900AG	1
29	Key	KE000900AV	KE000900AV	KE000900AV	KE000900AV	KE000900AV	KE000900AV	KE000900AV	1
30	Setscrew	ST026200AV	ST026200AV	ST026200AV	ST026200AV	ST026200AV	ST026200AV	ST026200AV	1
31	Pulley	PU012700AG	PU012700AG	PU012700AG	PU012700AG	PU012700AG	PU012700AG	PU012700AG	1
32	Square hd set screw	ST012200AV	ST012200AV	ST012200AV	ST012200AV	ST012200AV	ST012200AV	ST012200AV	1
33	Belt guard (back)	BG217902AV	BG217902AV	BG217902AV	BG217902AV	BG217902AV	BG217902AV	BG217902AV	1
34	Platescrew	ST058502AV	ST058502AV	ST058502AV	ST058502AV	ST058502AV	ST058502AV	ST058502AV	1
35	Belt guard (front)	BG217800AV	BG217800AV	BG217800AV	BG217800AV	BG217800AV	BG217800AV	BG217800AV	1
36	Self-tapping screw	ST073269AV	ST073269AV	ST073269AV	ST073269AV	ST073269AV	ST073269AV	ST073269AV	1
37	Self-tapping screw	ST042400AV	ST042400AV	ST042400AV	ST042400AV	ST042400AV	ST042400AV	ST042400AV	3
38	Filter assembly	--	--	--	--	ST073915AV	ST073915AV	ST073915AV	1
39	Filter element	--	--	--	--	ST073916AV	ST073916AV	ST073916AV	1
40	Belt guard (back)	--	--	--	--	--	--	--	--
41	Belt guard (front)	--	--	--	--	BG217601AV	BG217601AV	BG217601AV	1
42	#10 Flatwasher	--	--	--	--	BG217701AV	BG217701AV	--	1
43	#10-24 Nut	--	--	--	--	ST070906AV	ST070906AV	--	6
44	#10-24 Nut	--	--	--	--	ST163200AV	ST163200AV	--	4
44	#10-24 - 5/16" Self-tapping screw	--	--	--	--	ST042400AV	ST042400AV	--	2
45	Δ General warning decal set	DK630000AV	DK630000AV	DK630000AV	DK630000AV	DK630000AV	DK630000AV	DK630000AV	1
45	Δ Moving and mounting warning decal	DK364601AV	DK364601AV	DK364601AV	DK364601AV	DK364601AV	DK364601AV	DK364601AV	1
47	Δ Inspection port reducer 2" x 3/4"	PG201002AV	PG201002AV	PG201002AV	PG201002AV	PG201002AV	PG201002AV	PG201002AV	1
47	Δ Inspection port reducer 2" x 1/4"	PG201004AV	PG201004AV	PG201004AV	PG201004AV	--	PG201004AV	PG201004AV	1
47	Δ Inspection port reducer 2" x 3/8"	--	--	--	--	PG201006AV	--	--	1
48	Power cord 240V	ST209800AV	ST209800AV	ST209800AV	ST209800AV	ST209800AV	EC012901AV	ST209800AV	1
49	Strain relief screw	CW209700AV	CW209700AV	CW209700AV	CW209700AV	CW209700AV	CW209500AV	CW209700AV	1
50	Strain relief	ST070190AV	ST070190AV	ST070190AV	ST070190AV	ST070190AV	ST070190AV	ST070190AV	2
51	Δ Inspection port o-ring	--	--	--	--	--	--	--	--
Δ	Not shown	--	--	--	--	--	--	--	--



