

**For replacement parts or technical assistance, call 1-888-241-5858**

Please provide following information:

- Model number
- Serial number (if any)
- Part description and number as shown in parts list

Address parts correspondence to:

Attn: Parts Department  
100 Production Drive  
Harrison, OH 45030 U.S.A.

Ref. No.	Description	Part Number	Qty.
1	Exhaust deflector	SV490000AV	1
2	Hex. socket head bolt	SV490100AV	4
3	Spring washer	SV490200AV	6
4	Head cap	SV490300AV	1
5	Seal washer	*	1
6	O-ring	*	1
7	Internal lining	SV490600AV	1
8	O-ring	*	1
9	Compression spring	*	1
10	Balance valve	*	1
11	O-ring	*	1
12	O-ring	*	1
13	O-ring	*	1
14	O-ring	*	1
15	Ring	*	1
16	Piston	■	1
17	Driver blade	■	1
18	Collar	SV491600AV	1
19	O-ring	*	1
20	O-ring	*	1
21	Cylinder	SV491900AV	1
22	Bumper	SV492000AV	1
23	Gasket	*	1
24	Nozzle shield	SV489700AV	1
25	Nozzle	SV489600AV	1
26	Nozzle	SV492600AV	1
27	Driver guide	SV492700AV	1
28	Hex. socket head bolt	SV492800AV	2
29	Spacer	SV492900AV	1
30	Hex. socket head bolt	SV493000AV	2
31	Upper driver guide	SV493100AV	1
32	Driver guide cover	SV493200AV	1
33	Pin	SV493300AV	2
34	Pin	SV493400AV	1
35	O-ring	SV493500AV	1
36	Depth control guide frame	SV493600AV	1
37	Safety spring	SV493700AV	1
38	Depth control guide body	SV493800AV	1
39	Steel ball	SV493900AV	2
40	Spring	SV494000AV	2
41	Thumbwheel	SV494100AV	1
42	Upper work contact element	SV494200AV	1
43	Lower work contact element	SV494300AV	1
44	No-nar tip	SV494400AV	1
45	Spring washer	SV494500AV	3
46	Hex. socket head bolt	SV494600AV	1
47	Inner seal	▲ *	1
48	Upper valve body	SV494800AV	1
49	Inner trigger spring	SV494900AV	1
50	O-ring	▲ *	2

Ref. No.	Description	Part Number	Qty.
51	Trigger valve plunger	SV495100AV	1
52	O-ring	▲ *	1
53	Lower valve body	SV495300AV	1
54	Trigger spring	□	1
55	Trigger plate	□	1
56	Spring pin	□	1
57	Trigger	□	1
58	Pin for trigger	□ *	1
59	O-ring	□ *	1
60	Bushing	SV496000AV	1
61	Torsion spring	SV496100AV	1
62	Quick release latch	SV496200AV	1
63	Hex. socket head bolt	SV496300AV	1
64	Button cover	SV496400AV	1
65	Magazine B	SV496500AV	1
66	Pusher	◆	1
67	Spring holder	◆	2
68	Pusher spring	◆	2
69	Magazine A	SV496900AV	1
70	Spring washer	SV497000AV	1
71	Hex. socket head bolt	SV497100AV	1
72	Flat head screw	SV497200AV	1
73	Magazine end stop	SV497300AV	1
74	Magazine pad	SV497400AV	1
75	Spring pin	SV497500AV	1
76	Spring	SV497600AV	1
77	Magazine latch button	SV497700AV	1
78	Spring pin	SV497800AV	1
79	Tail hanger	SV497900AV	1
80	Hex. socket head bolt	SV498000AV	2
81	End hollow cover	SV498100AV	1
82	Hand grip	SV498200AV	1
83	O-ring	*	1
84	End cap	SV489800AV	1

**REPLACEMENT PARTS KITS**

- ◆ Pusher assembly
- ▲ Trigger valve o-ring kit
- Driver kit
- Balance valve assembly
- Trigger assembly
- \* Complete o-ring replacement kit



**2-in-1 Nailer/Stapler**

