


## *Replacement Parts List*

| KEY | DESCRIPTION | PART NUMBER FOR MODEL VT614803 | PART NUMBER FOR MODEL VT617102 | QTY |
|---|---|---|---|---|
| 1 | Compressor pump | VT232605KB | VT232605KB | 1 |
| 2 | Air receiver (tank) | AR019500JY | AR019500JY | 1 |
| 3 | * 5/16 - 18 x 1 1/4 Screw | ST012800AV | ST012800AV | 4 |
| 4 | * 5/16 - 18 Locknut | ST146000AV | ST146000AV | 8 |
| 5 | Drain cock | D-1401 | D-1401 | 1 |
| 6 | Rubber foot | ST041600AV | ST041600AV | 2 |
| 7 | Compression connector | ST018300AV | ST018300AV | 1 |
| 8 | Discharge tube | VT035500AP | VT035500AP | 1 |
| 9 | Compression nut | ST033001AV | ST033001AV | 1 |
| 10 | Ferrule | ST067300AV | ST067300AV | 1 |
| 11 | Compression connector | ST072019AV | ST072019AV | 1 |
| 12 | Load Genie | ST128401AV | ST128401AV | 1 |

## *Replacement Parts List*

| KEY | DESCRIPTION | PART NUMBER FOR MODEL VT614803 | PART NUMBER FOR MODEL VT617102 | QTY |
|---|---|---|---|---|
| 13 | Silencer | ST154900AV | ST154900AV | 1 |
| 14 | * 1/2" Close nipple | ST070303AV | ST070303AV | 1 |
| 15 | 90° Compression connector | ST015500AV | ST015500AV | 1 |
| 16 | Brass insert | ST079600AV | ST079600AV | 2 |
| 17 | Unloader tube | ST079701AV | ST079701AV | 1 |
| 18 | † Gas engine | NG002300AV | NG002502AV | 1 |
| 19 | * 5/16 - 18 x 1 3/4 Hex head screw | ST070625AV | ST070625AV | 4 |
| 20 | * Washer | ST011200AV | ST011200AV | 8 |
| 21 | Motor pulley | PU014200AG | PU014200AG | 1 |
| 22 | Belt V, B-section | BT008800AV | BT008800AV | 1 |
| 23 | 3/16 x 3/16 x 1 1/4 Key | KE000903AV | KE000903AV | 1 |
| 24 | * 1/4 - 20 x 1/2" Square head set screw | ST012200AV | ST012200AV | 1 |
| 25 | Screw, from compressor pump | — | — | — |
| 26 | Long brace assembly | BG208800AJ | BG208801AJ | 1 |
| 27 | * 5/16 - 18 Nut | ST018700AV | — | 1 |
| 28 | * 5/16 Lockwasher | ST015100AV | — | 1 |
| 29 | Throw cylinder assembly | V-214801AJ | CV003500AV | 1 |
| 30 | Throw cylinder rod | ST123501AV | — | 1 |
| 31 | * 10 - 32 x 1/2 Hex head screw | ST070608AV | — | 1 |
| 32 | * #10 Split lockwasher | ST046400AV | — | 1 |
| 33 | Screw | — | ST080702AV | 2 |
| 34 | Spring | — | ST080012AV | 1 |
| 35 | Nut | — | ST076909AV | 1 |
| 36 | Strike bracket | — | BG021000AV | 1 |
| 37 | Nut | — | ST140200AV | 1 |
| 38 | Bracket | — | BG021100AV | 1 |
| 39 | Coupling | — | ST163001AV | 1 |
| 40 | † Bracket, from engine | — | — | 1 |
| 41 | 90° Compression connector | — | ST015500AV | 1 |
| 42 | Belt guard channel | BG020001AV | BG020001AV | 1 |
| 43 | Belt guard | BG020101AV | BG020101AV | 1 |
| 44 | Plascrew | ST058502AV | ST058502AV | 1 |
| 45 | * 10 - 24 x 5/16 Screw | ST042400AV | ST042400AV | 6 |
| 46 | Belt guard bracket | BG014014AL | BG014014AL | 1 |
| 47 | Belt guard kit, includes key nos. 41 - 45 | BG300000AJ | BG300000AJ | 1 |
| 48 | Axle bolt | ST033400AV | ST033400AV | 2 |
| 49 | 10" Wheel | WA002500AV | WA002500AV | 2 |
| 50 | Hex keps nut | ST033500AV | ST033500AV | 2 |
| 51 | Handle | HL001800BH | HL001800BH | 1 |
| 52 | Handle screw | ST073236AV | ST073236AV | 1 |
| 53 | * 1/2 - 14 - 1/4 90° Elbow | ST071204AV | ST071204AV | 1 |
| 54 | Filter element | ST073914AV | ST073914AV | 1 |
| 55 | Filter assembly with element (optional) | MP292900AJ | MP292900AJ | 1 |
| 56 | * 1/8 - 27 NPT pipe plug | ST022400AV | ST022400AV | 1 |
| 57 | Nipple | HF002401AV | HF002401AV | 1 |
| 58 | Regulator/manifold body | RE009302AG | RE009302AG | 1 |
| 59 | Hose connector | HF002400AV | HF002400AV | 1 |
| 60 | ASME Safety valve | V-203600BL | V-203600BL | 1 |
| 61 | Screw | ST073224AV | ST073224AV | 2 |
| 62 | * Plug | ST022500AV | ST022500AV | 2 |
| 63 | Gauge | GA016101AV | GA016101AV | 2 |
| 64 | O-ring | ST110700AV | ST110700AV | 1 |
| 65 | Plug | MT000300AV | MT000300AV | 1 |
| 66 | O-ring | ST070162AV | ST070162AV | 1 |
| 67 | Spring | RE010300AV | RE010300AV | 1 |
| 68 | Valve stem | RE010100AV | RE010100AV | 1 |
| 69 | Valve seat | RE010000AV | RE010000AV | 1 |
| 70 | O-ring | ST070161AV | ST070161AV | 1 |
| 71 | O-ring | ST070160AV | ST070160AV | 1 |
| 72 | Regulator piston | RE009900AV | RE009900AV | 1 |
| 73 | Spring | ST114500AV | ST114500AV | 1 |
| 74 | Spring plate | RE009800AV | RE009800AV | 1 |
| 75 | O-ring | ST070180AV | ST070180AV | 1 |
| 76 | Regulator top assembly | RE010401AJ | RE01041AJ | 1 |
| 77 | Adjusting knob | RE009701AV | RE009701AV | 1 |
| 78 | Manifold shroud | RE010700AV | ST070160AV | 1 |
| 79 | Compressor pump flywheel | PU007300AG | PU007300AG | 1 |
| 80 | Compressor pump key | KE000900AV | KE000900AV | 1 |
| 81 | Compressor pump setscrew | ST026200AV | ST026200AV | 1 |

† Engine parts, available from engine manufacturer.
* Standard hardware item, available locally.